

Serial No.:

Date:

Sheet of

ORDER TO OPERATE (PC 17)

Note:

- Orders to operate must be performed in the number sequence listed
- A group of operations listed under one sequence number may be performed by any sequence
- Apparatus must be in the position stated in "OPERATION" column

Purpose of Order: To isolate 54G1 Excitation system

Sequence Number	Device	Remove tag no.	Operation	Place tag no.	initials
1.	54G1F		Turn selector to Local and Open		
2.	1B15		Open		
3.	1B30		Open		
4.	4B21		Open		
5.	67S15		Open		
6.	4S7		Open and rack out		
7.	5S1		Open and rack out		
Prepared By: Boadu		Checked By:	Ordered By:		Completed By:
Time:		Time:	Time:		Time:
Date:		Date:	Date:		Date:
Pin board or Mimic board changed by:			PC 2 Serial Number:		